

Puukalusteiden ja kesäkalusteiden hoito-ohjeet

Puu tarvitsee luonnostaan hoitoa. Seuraamalla alla olevia ohjeita saat kalusteistasi iloa monen vuoden ajan. Vaikka puu olisikin käsitelty hoitoaineella, silti liian kertyminen pinnalle ja kosteus saattavat aiheuttaa pintahomeen muodostumista. Suojaa siis kalusteet liialta ja sään vaikutuksilta esimerkiksi KATOKSEN ALLA TAI SUOJAPEITTEELLÄ Älä koskaan peitä kosteita tai märkiä kalusteita ja vältä suoraa maakosketusta. Huomaa, että puun halkeilu on normaali puun ominaisuus, johon vaikuttavat lämpötilan- ja kosteudenvaihtelut, varsinkin ulkokäytössä voimakkaammin. Edellä mainitut asiat voivat vaikuttaa myös puun vääntymiseen, joka on myös puun ominaisuus. Tuote on valmistettu havupuusta, joten pihkaantumista voi esiintyä varsinkin oksien kohdalla, joka ilmenee lähinnä kellastumisena.

Puhdistus: miedolla puhdistusaineliuksella. Kuivaus puhtaalla ja kuivalla liinalla.

Hoito: Ulkokalusteiden käyttöaikää voi pidentää yksinkertaisella ja SÄÄNNÖLLISELLÄ HOIDOLLA. Pyri pitämään kalusteet puhtaina ja kuivina. Väriin muuttuminen, pienet halkeamat ja kuiva pinta ovat merkkejä uudelleen käsittelyn tarpeesta. Säännöllinen, noin 1 – 2 kertaa vuodessa tapahtuva käsittely vesiohenteisella puunsuoja - aineella suojaa kalusteita kulumiselta. Tämä ulkokaluste on käsitelty ympäristöystävällisellä petsillä ja kosteudenestolakkalla, jotka siis ovat veisiohenteisiä. Kysy uudelleen käsittelyä varten ohjeita maalikaupasta. Säilytys: Säilytä ulkokalusteet mieluiten kuivassa ja viileässä sisätilassa. Jos säilytät niitä ulkona, säilytä ne kallellaan vedenkestävän peitteen alla. Varmista, että ilma pääsee kiertämään peitteen alla, jotta kalusteet eivät kostu ja homehdu.

Care instruction for wooden furniture and garden furniture

Wood products require maintenance to stay looking good. If you follow the instructions below, you'll be able to enjoy your garden furniture for many years to come. Wood as organic material is susceptible to various weather conditions such as moisture, dryness, sun and wind, and therefore may become dull, faded and damaged. Although our furniture is treated with a wood protection agent, however dirt and moisture can cause mould on the surface of the furniture. Therefore, protect your furniture from dirt and weather, putting it under the roof or use protective coverings. Never cover the wet furniture and keep your furniture away from direct contact with a damp or wet ground.

We would like to draw your attention to the fact that splitting is a normal characteristic of wood caused by fluctuation in temperature and moisture. In outside conditions these changes are greater. The above mentioned factors may also cause twisting of wood which is also a normal characteristic. The product is made of conifer, as a result there may occur tree sap on knots which may turn yellowish in the course of time. Cleaning: With a mild soapy solution. Wipe dry with a clean and dry cloth.

Maintenance: With simple, regular maintenance your outdoor furniture will last longer. Try to keep the furniture clean and dry. Colour changes, small cracks and a dry surface are signs that it is time to re-glaze your furniture. You can easily protect your furniture against wear and tear by reglazing it on a regular basis, about 1-2 times a year. This outdoor furniture is processed with an environmentally friendly stain and waterproof wax. Both are water-based. For maintenance please ask for instructions in a paint shop.

Storing: If possible, store your outdoor furniture in a cool, dry place indoors. If you need to store the furniture outdoors, tilt it and cover it with water repellent covers. Allow air to ventilate, to avoid moisture and mould.