











veke

Harso vitriini korkea











① x37	② x2	③ x4	④ x2	⑤ x4
				
Ø5*12mm	Ø6*30mm	Ø12*0.8mm	Ø4*24mm	62*62mm
⑥ x2	⑦ x12	⑧ x2	⑨ x4	⑩ x4
				
		15*76mm		
⑪ x2	⑫ x2			
				
Ø8*38mm	Ø4*38mm			






1










2







3






4



5








6



spare parts of glass buckle

7





Gaps may appear between the top of the doors and the frame if the unit is placed on uneven ground. Use the plastic foot caps to adjust the level.

9

