







METAL NESTING TABLE INSTRUCTION MANUAL



PB1
1X

PB2
1X

PB3
1X

BP1
2X


BP2
2X

BP3
2X


P1
1X

P2
1X

P3
1X



PB1 448x407 mm
PB2 448x357 mm
PB3 448x307 mm



NO: H100001
3,5x50 MM







12 X

NO: H100008
5x50 MM





06 X






1H100008
2x

H0009



2H100001
4x

10 KG

PB1




**3**H100008
2x

H0009



4H100001
4x

10 KG

PB2

**5**H100008
2x

H0009

6H100001
4x

10 KG

PB3

